

- 1 Cut door to enable the mortice lock to sit flush with the outer edge of the rebate in the door.
- 2 Fit part A to enable lock to be fitted flush with outer edge of the rebate.
- 2 Position and fit rebate striker to door jam to suit mortice lock (Marked B).

